Poppet Valves

Emergency Manual Override

Manual override available for electric valves

The manual override described below are available for all versions of electric valves, size and dimensions do not vary according to the size of the solenoid valve. It is important to know that these configurations are designed to not be recommended for frequent use.

Dimension and operating mode

For information on the fuctioning or on the various configuration options, please contact us.

Push (P)



Pressing the button, the valve switches position

Push and Twist (PT)



Pressing and turning the button of 90° the valve switches position and remains in position due to the detent

Push Pin (EC)



Pushing the pin, using a tool smaller than 4.1mm. the valve switches position.

Screw in (SV)



Rotating the knob clockwise the valve switches position.

Poppet Valves

Emergency Manual Override

Pull (T)



Pulling the nut the valve switches position



Note: To avoid breaking do not apply a force greater than 40 N

Screw out (s)



Rotating the knob anti-clockwise the valve switches position



Lever (L)





For 3 position cartridge valve pushing or pulling the lever makes the valve switch position